

# Aerodynamics Lab – I

## (AE29202)

### Verification of Bernoulli's Theorem




Dr. Sunil Manohar Dash

Assistant Professor

Department of Aerospace Engineering

Email: [smdash@aero.iitkgp.ac.in](mailto:smdash@aero.iitkgp.ac.in)

# What is Bernoulli's Theorem?



This theorem states that an increase in the speed of the moving fluid is accompanied by a decrease in the fluid's static pressure.

In other words, sum of the kinetic (velocity head), pressure (static head) and potential energy at any point in the flow remains constant provided that the flow is **incompressible, steady, irrotational and frictionless**.

# What is Bernoulli's Theorem?

Energy per unit volume before = Energy per unit volume after


$$P_1 + \frac{1}{2}\rho v_1^2 + \rho gh_1 = P_2 + \frac{1}{2}\rho v_2^2 + \rho gh_2$$

Pressure  
Energy

Kinetic  
Energy  
per unit  
volume

Potential  
Energy  
per unit  
volume

The often cited example of the Bernoulli Equation or "Bernoulli Effect" is the reduction in pressure which occurs when the fluid speed increases.



# What are Different Types of Pressure in a Fluid Flow?

## ➤ Static Pressure:

- Static pressure is the pressure felt at a point by virtue of the state of the fluid.
- In case of stationary fluid it is called hydrostatic pressure. In case of a flow, the static pressure measurement is taken perpendicular to the fluid flow direction or by moving with the fluid.

## ➤ Total or Stagnation Pressure

- If the fluid at a point is brought to rest with an isentropic and adiabatic process, the pressure rises until a maximum that is called the total pressure.


## ➤ Dynamic Pressure

- The dynamic pressure is the difference between the total and the static pressure.


# Pressure Measurement

## Pitot-Static Tube

- A pitot-static tube is used for measuring the total and static pressures simultaneously.
- It is usually a blunt-nosed tube with an opening at its nose to sense the total pressure and a set of holes on the surface of the tube to sense the static pressure.
- The accuracy in static pressure measurement using static tubes depends mainly on the position of the sensing holes with respect to the nose of a tube and its supporting stem.
- If the static pressure ports are close to nose or stem, acceleration effects caused by the nose tend to lower the static pressure; stagnation effects caused by the stem tend to raise the tap pressure. In a properly compensated tube, these two effects will just cancel at the plane of the pressure holes. Refer the figure.



Pitot-static probe




Pressures due to nose and stem of a static probe

# Pressure Measurement

## Pitot-Static Tube

### Working Principle (Incompressible Flow)

- Pressure taps sensing static pressure (also the reference pressure for this measurement) are placed radially on the probe stem and then combined into one tube leading to the differential manometer ( $p_{stat}$ ).
- The pressure tap located at the probe tip senses the stagnation pressure ( $p_0$ ).
- Use of the two measured pressures in the Bernoulli equation allows to determine one component of the flow velocity at the probe location.



$$p_0 = p_{stat} + \frac{1}{2} \rho V^2, (Bernoulli)$$

$$V = \sqrt{2(p_0 - p_{stat}) / \rho}$$


$$V = \sqrt{2(p_0 - p_{stat}) / \rho}$$

$p_0$  = stagnation pressure

$p_{stat}$  = static pressure

# Verification of the Bernoulli's Theorem

Can we get velocity information without Bernoulli's Theorem?





# What is Continuity Equation?

The continuity equation states the conservation mass in a fluid flow domain.

For a control volume, the principle of conservation of mass is stated as

Rate at which mass enters CV = Rate at which mass leaves the CV + Rate of accumulation of mass in the CV

For a steady and incompressible flow




**A Control Volume in a Flow Field**




# Report Format

1. Aim of the Experiments
2. Objectives
3. Experimental Procedure
4. Observations
5. Results and Discussion
6. Conclusions
7. Questionnaires
8. Ansys Fluent Simulations (optional)




Venturi Test Section

# Experimental Setup and Procedure



Airflow Bench

A (in cm <sup>2</sup> ) (cross sectional area)	Length (in cm)
37.25	0
35.00	1
33.00	2
31.00	3
28.00	4
26.00	5
24.00	6
21.00	7
21.00	8
21.00	9
21.00	10
21.00	11
21.00	12
22.00	13
23.00	14
24.00	15
25.00	16
26.00	17
27.00	18
27.50	19
28.00	20
29.00	21
30.00	22
31.00	23
32.00	24
32.50	25
33.00	26
34.00	27
35.00	28
36.00	29
37.00	30



Venturi Test Section

# Observation Table

Group - 1						
Global static pressure = 269 mm H <sub>2</sub> O						
Global total pressure = 306 mm H <sub>2</sub> O						
Global velocity = 24.9646 m/s						
Length (in cm)	Total pressure (mm of water)	Static pressure (mm of water)	V <sub>b</sub> (in m/s) From Bernoulli's equation	A (in cm <sup>2</sup> ) (cross sectional area)	V <sub>c</sub> (in m/s) From the continuity equation	Error of V <sub>c</sub> (in %)
0	306	269		37.25		
1	306	260		35.00		
2	306	252		33.00		
3	306	242		31.00		
4	306	234		28.00		
5	306	220		26.00		
6	306	202		24.00		
7	306	190		21.00		
8	306	184		21.00		
9	306	182		21.00		
10	306	181		21.00		
11	306	180		21.00		
12	306	182		21.00		
13	306	186		22.00		
14	306	191		23.00		
15	306	198		24.00		
16	306	203		25.00		
17	306	208		26.00		
18	306	212		27.00		
19	306	216		27.50		
20	306	220		28.00		
21	306	224		29.00		
22	306	227		30.00		
23	306	230		31.00		
24	306	231		32.00		
25	306	233		32.50		
26	306	238		33.00		
27	306	240		34.00		
28	306	242		35.00		
29	306	243		36.00		
30	306	244		37.00		

# Sample Calculation

Total pressure ( $P_T$ ) = 306 mm of water = 0.306 m of water =  $0.306 \times 9.81 \times 1000 \text{ Pa} = 3001.86 \text{ Pa}$

Static pressure ( $P_S$ ) = 234 mm of water = 0.234 m of water =  $0.234 \times 9.81 \times 1000 \text{ Pa} = 2295.54 \text{ Pa}$

Density of air ( $\rho$ ) =  $1.23 \text{ Kg/m}^3$

From Bernoulli's equation,  $V_b^2 = 2 \times (P_T - P_S) / \rho$

$$V_b^2 = 2 \times (3001.86 - 2295.54) / 1.23$$

$$V_b^2 = 1148.48$$

Thus,  $V_b = 33.89 \text{ m/s}$ .



From Continuity equation,  $V_c = (A_0 \times V_0) / A_{4,\text{cm}}$

$$V_c = (37.25 \times 24.29453) / 28$$

So,  $V_c = 32.32 \text{ m/s}$ .


Error of  $V_b$  (in %) =  $(V_b - V_c) \times 100 / V_c$

$$= (33.89 - 32.32) \times 100 / 32.32$$

$$= 4.85.$$

# Plots to Include in the Report

1. Velocity vs Length (Both Bernoulli's and Continuity Equation)
2. Static Pressure vs Length
3. Total Pressure vs Length
4. Error vs Length
5. Comparison of experimental results with ANSYS Fluent Simulation (Optional)



# Questionnaire

1. Name four fluid flow types that do not follow Bernoulli's theorem?
2. Why the velocities obtained from continuity and Bernoulli's equation do not match on the venturi section in your experiment?
3. Is the flow incompressible in your experiment? How do you confirm this?





**Thank you**  
RESEARCH LAB